

For more information please visit: www.thinktankphoto.com

ADJUSTABLE STERNUM STRAP



The sternum strap adjusts up and down along the blue rails on the backpack straps.

REMOVABLE WAISTBELT



The included waistbelt is removable by unthreading the webbing through the buckle.

ATTACH A MODULAR BELT



Remove the StreetWalker waistbelt. Pass a Think Tank Photo Pro Speed Belt™ or Thin Skin™ Belt (sold separately) into place for additional comfort or to be used with the Think Tank Modular Belt system. *Belt pass through available on the StreetWalker HD and StreetWalker Pro only.

TRIPOD OR MONOPOD ATTACHMENT



Step 1: Locate the two adjustable tripod straps provided with the StreetWalker.



Step 2: To open the Double Gatekeeper buckle, press the gate inwards then depress the top plastic bar in order to release the gate.



Step 3: Slide the opened Double Gatekeeper buckle through the webbing loop and close it by depressing the top plastic bar and securing the gate.



Step 4: Attach the tripod straps to the webbing loops at the top and near the bottom of the StreetWalker.

For more information please visit: www.thinktankphoto.com

CARRYING A TRIPOD



Step 1: Insert two tripod legs into the outside lower pocket.



Step 2: Unlock the adjustable strap, then pull the strap tight around the top of the tripod. Tighten the lower strap around the exposed leg for additional stability.

USING THE TRIPOD CUP



Step 1: Locate the blue tab with the tripod icon near the bottom of the StreetWalker Pro and StreetWalker HardDrive.



Step 2: Pull tab downward to deploy the tripod cup. Use the included tripod straps to secure the tripod onto the backpack.