


(Household Use Only)

Instruction Manual

Name of Each Part



The illustrations used in this instruction manual may vary from the actual product you have purchased.

Please read these instructions before use, and keep for future reference.

SM-JTE(E/K) / C

Important Safeguards


Please follow these instructions to prevent scalding, deterioration and discoloration of beverages, as well as malfunction and staining of the Mug.

Do not allow infants or small children to use this product. Keep out of the reach of infants and small children.

Mishandling may cause injury or scalding.

Do not place near heat sources such as gas stoves, ovens and heaters. Doing so may cause deformation or discoloration of the Mug.

Leave 1cm (1/2-inch) room on top when filling the Main Body.



Be careful not to over fill the Main Body. Over filling may cause leakage.

When containing hot beverages:

- Do not shake the Mug.
 - Doing so may cause scalds or injury.
- Be careful not to scald yourself when drinking out of the Mug. Due to its vacuum insulation, the

outside of the Mug will not become hot, while hot beverages will remain very hot for many hours. Please use caution when drinking.

● Always make sure to use with the Lid Cover attached.

The interior of the Lid Set may become hot and cause scalds or injury.

Do not push the Mesh part when attaching the Tea Leaf Filter Set to the Main Body.

You may unintentionally touch hot beverages and be scalded.

Do not use if the Mug loses its heat retention properties.

The outside of the Main Body may become very hot if hot beverages are poured inside.

Always close the Lid Set securely.

Hot beverages may leak and cause scalding.

Do not drink out of the Mug while driving. Always close the Lid Set securely after drinking.

Doing so may cause scalds or stain the interior of the car or clothes. Attempting to use while driving may also cause serious accidents.

When using a vehicle cup holder accessory:

- 1) Always keep the Lid Set securely closed when not drinking.

 Beverage may spill if the Mug is tipped over, causing scalds or injury.
- ②Make sure the Mug fits into the holder securely before placing it in.

 Do not use the Mug if it does not fit into the holder securely as it may tip over and cause scalds, injury or accidents.
- **3Check that the strength of the cup holder is sufficient to hold the Mug before using.**
 - The Mug may fall and cause injuries or burns, or stain the interior of the car or clothes if the cup holder does not hold up.
- (4) Do not use a hanging-type cup holder that attaches to the window or air vent. The cup holder may fall off.
- The Mug may not fit into some cup holders.

Important Safeguards

Please follow these instructions to prevent scalding, deterioration and discoloration of beverages, as well as malfunction and staining of the Mug.

Do not heat in a microwave.

Doing so may cause sparks, deform or discolor the Mug.

Do not remove the sticker on the bottom of the Main Body.

Doing so may cause rust or holes.



This Mug is for holding beverages and keeping them hot or cold.

Please do not use for other than intended purposes.

Clean the Main Body after every use. Not cleaning thoroughly may cause the Main Body to rust, beverages to spoil, or cause pinholes.

Do not disassemble the Main Body.

Consume beverages within the same day to prevent from spoiling.

Beverages left inside for a long period of time may spoil and produce gas that may cause the Lid Set to burst or beverages to spill, causing injuries and scalds.

When filling the Mug with sports drinks:

- ■Rinse the inside of the Main Body as soon as possible after consumption to prevent rust and/or pinholes.
- Clean the inside using a soft sponge to protect the nonstick coating from being scratched.

Do not fill the Mug with the following:

- Dry ice and carbonated drinks:
 - Contents may spill out or the pressure may cause the Lid Set to burst, causing injuries.
- •Liquids high in sodium such as soup and Kobu-cha:

Although the liner is made of 18/8 stainless steel and is nonstick coated, salt may cause rust resulting in loss of thermal insulation.

- Dairy products and fruit juice:
 - If left inside for a long period of time, contents may spoil and produce gas that may cause the Lid Set to burst, causing injuries.
- ●Fruit pulp:

May become caught on the Stopper Gasket and cause contents to spoil.

Always make sure the Stopper, Lid Cover, Valve Packing, Stopper Gasket and Tea Leaf Filter Gasket are attached.

Contents may leak and/or cause scalding.

Warnings & Cautions

Do not attempt to carry the Mug by the Tea Leaf Filter Handle.

The Tea Leaf Filter Set may come off and the Main Body may fall, causing injuries or scalds. Do not allow tealeaves or the string of a teabag to become caught on the gaskets, as doing so may cause leaks.

Do not hold the Mug by the Lid Set or Lid Cover.

The Mug may drop and cause injuries.

Warnings & Cautions, continued

Do not allow hot kettles to touch the mouth of the Main Body.

The Mug may tip over, causing scalds.



Clean the Stopper, Valve Packing, Stopper Gasket, Tea Leaf Filter and Tea Leaf Filter Gasket after every use.

Not doing so may cause decay, mold, odor or discoloration. It may also cause leaks.

The rattling noise that may be heard when the Main Body is shaken comes from the copper or aluminum foil in the vacuum insulation to increase heat (cold) retention and does not indicate a malfunction.

Do not tilt the Main Body suddenly when drinking.

The beverage may spill and cause scalding or stain clothes.

Do not force large ice cubes in.

Doing so may cause deformation or damage to the product.

Do not rub the design on the outside of the Main Body strongly.

It may come off.

Avoid dropping or hitting against hard surfaces.

Damage to the plastic or stainless steel surface of the Mug may reduce its ability to retain heat.

Do not attach parts other than those specifically for this product.

Doing so may cause leaks or breakage.

Always disassemble the Lid Set when washing then wipe dry. Water may collect inside the Lid Set and drip out if not dried well.

Close the Lid Set securely after drinking.

Store the Mug upright when carrying inside bags to prevent beverages from spilling.

When removing the Tea Leaf Filter Set, please use caution as the Tea Leaf Filter Handle may be hot.

Scalding may occur.

How to Use


Before use, rinse the Lid Set, Tea Leaf Filter Set, and the interior of the Main Body thoroughly with lukewarm water.

Remove the Lid Set and Tea Leaf Filter Set from the Mug.

Remove the Lid Set

Remove the Lid Set from the Mug by turning it counterclockwise as illustrated.

Please remove not only the Lid Cover but also the Lid Set and the Tea Leaf Filter Set.




How to Use, continued

Place tealeaves in the Main Body, fill with hot water, attach the Tea Leaf Filter Set, and close the Lid Set.

- ■Be sure that the Lid Cover, Lid Cover Gasket, Stopper, Valve Packing, Stopper Gasket and Tea Leaf Filter Gasket are attached properly to prevent beverages from leaking.
- Close the Lid Set securely with the Mug at an upright position.
- Always use the Lid Set with the Lid Cover firmly attached.
- Attach the Lid Set properly and turn the Mug upside down to make sure contents do not leak.
- If there are too much tealeaves or hot water, discard a small amount and close the Lid Set. Please refer to the illustration below and make sure not to fill above the Drink Level.
- Hot water may splatter when filling. Please be careful of scalding.
- Adjust the amount of tealeaves according to taste.
- ●When attaching the Tea Leaf Filter Set onto the Main Body, make sure not to push the mesh.

You may unintentionally touch hot beverages and be scalded. Also, be careful as steam may cause scalding.




Remove the Lid Set and drink the beverage with the Tea Leaf Filter Set attached.

- Tealeaves finer than the Tea Leaf Filter Set mesh may flow out with the beverage.
- Please make sure that the Tea Leaf Filter Set is attached to the Main Body securely.
- Please drink with the Tea Leaf Filter Handle folded down. If the Tea Leaf Filter Handle is up, it may fall when drinking and hit your lip or face, resulting in scalds.
- When removing the Tea Leaf Filter Set, please use caution as the Tea Leaf Filter Handle may be hot.

After drinking, close the Lid Set by turning it clockwise.

- Make sure the Tea Leaf Filter Handle is folded down when closing the Lid Set.
- Do not attempt to carry the Mug by the Tea Leaf Filter Handle. The Tea Leaf Filter Set may come off and the Main Body may fall, causing injuries or scalds.



Mesh

How to Disassemble the Parts

Lid Set




Remove the Lid Cover.

Hold the Tab and pull apart as illustrated.



2 Remove the Stopper.


Push the Tabs in as illustrated by the triangles to remove.





Remove the Lid Cover Gasket.
Remove the Lid Cover Gasket utilizing the Small Opening.








Tea Leaf Filter Set





How to Assemble the Parts


Tea Leaf Filter Set






Lid Set








How to Assemble the Parts, continued



4 Attach the Stopper to the Stopper Cover.

Align the openings of the Stopper Cover and the tabs of the Stopper, and press Opening : the Stopper in to attach securely.


Please make sure that both tabs click in securely.





5 Attach the Lid Cover.

Align the tab on the underside of the Lid Cover with the opening on the Stopper Cover and attach firmly.



How to Take Care of Your Mug

Always clean the Mug after use

When cleaning the Lid Set and the Tea Leaf Filter Set, be sure to disassemble them into parts.

Exterior, Lid Set and Tea Leaf Filter Set

- **Wash with warm water and mild dishwashing liquid using a** soft sponge.
- 2 Rinse, shake a few times and wipe dry.
- Disassemble the Lid Set and Tea Leaf Filter Set and remove all valves and gaskets before cleaning and drying.
- Please use a small brush (sold in stores) if necessary.
- Continued use of tealeaves may cause the interior of the Main Body to discolor. Although the discoloration may not be removed completely, it will not affect use.

Interior

- (1) Wash with warm water and mild dishwashing liquid using a soft sponge with handle.
- ②Then rinse and wipe moisture out to dry.
- Keeping the inside clean will help prevent odors.

When Cleaning Your Product:

- ●To protect the paint, print or stickers on the outside of the Main Body:
 - Do not use a dishwasher or dish-dryer. Do not boil to sanitize.
 - · Do not use bleach on the outside of the Main Body.
- Do not clean with thinner, benzene, abrasive cleaners or other harsh cleaners.
- Do not use chlorine type bleach.
- The product is washable, but do not soak it in water for an extended period of time.
- Wipe moisture off thoroughly to prevent water stains or rusting.
- Thoroughly wipe off any water between the Lid Cover and the Lid Set.

How to Take Care of Your Mug, continued

To Remove Rust Spots and Water Stains:

You may find rust spots or water stains caused by impurities in the water. To remove these stains, fill the Main Body with hot water with 10% vinegar and let it stand for 30 minutes to an hour without attaching the Lid Set and the Tea Leaf Filter Set, then wash the interior thoroughly.

To Remove Coffee and Tea Stains:

To remove coffee and tea stains from the interior, the Lid Set and the Tea Leaf Filter Set, we recommend using Zojirushi's cleaning detergent SB-ZA01E. Always remove the Lid Set and the Tea Leaf Filter Set when using SB-ZA01E. Contact Zojirushi Customer Service or your local dealer for further information.

Replacing the Lid Set, Stopper Gasket, Lid Cover Gasket and the Tea Leaf Filter Set We take care in only using materials that are safe and hygienic for food contact. However, if plastic parts become damaged or its surface becomes rough, please replace them for optimum performance. The Lid Set, Stopper Gasket, Lid Cover Gasket and the Tea Leaf Filter Set may need to be replaced due to time and wear. Please check them about once a year. When replacing parts, please record the model number and part name beforehand. Then contact either the store where you purchased the product or Zojirushi Customer Service. Replacement parts may be available for an additional charge.

SPECIFICATIONS:

Product:	STAINI	ESS	MHG
Froduct.	OLAHAL	_⊏ऽऽ	MUG

Model No.	Capacity	Weight	Heat Retention	Cold Retention
SM-JTE34	0.34 liter (11 oz.)	0.22 kg (8 oz.)	86°C (187°F) @ 1 hr. / 66°C (151°F) @ 6 hrs.	9°C (48°F) @ 6 hrs.
SM-JTE46	0.46 liter (16 oz.)	0.26 kg (9 oz.)	87°C (189°F) @ 1 hr. / 70°C (158°F) @ 6 hrs.	9°C (48°F) @ 6 hrs.

Heat/Cold Retention Testing Conditions:

At a room temperature of 20°C±2°C (68°F±4°F), the Main Body is filled to the neck with hot or cold water and left standing in an upright position. For heat retention, once the hot water reaches 95°C±1°C (203°F±2°F), the temperature is measured after 1 hour and 6 hours. For cold retention, once the cold water reaches 4°C±1°C (39°F±2°F), the temperature is measured after 6 hours.

Materials: Inner Liner Stainless Steel (Nonstick Coated)
Exterior Stainless Steel (Acrylic Resin Painted)

Tea Leaf Filter Handle
Tea Leaf Filter
Mesh
Stopper
Stainless Steel
Polypropylene
Polypropylene

Gasket & Packing Silicon

Manufacturer: Zojirushi Corporation

Address: 1-20-5 Tenma, Kita-ku, Osaka 530-8511, Japan